

图7-22 解释断面图(RSA883LM-884LM)




图7-22 解释断面图 (Line RSA883LM, 884LM) 深度断面图 (1:50,000)